


MAINTENANCE MANUAL

HUOLTO-OHJE

UNDERHÅLLSMANUAL

VEDLIKEHOLDSMANUAL


VEDLIGEHOLDELSSESVEJLEDNING






1


1




2




2




3




4




2




5



6




7





2


1





2





3




4







Art. Nr. 241.868.00.1




Art. Nr. 816.418.00.1




1




2



3



4




5




Spare part Art. Nr. 240.771.00.1


6



7



8



Geberit Oy
Tahkotie 1,
FI-01530 Vantaa
Myynti.fi@geberit.com
www.geberit.fi

Geberit AS
Luhrtoppen 2,
NO-1470 Lørenskog
Sales.no@geberit.com
www.geberit.no

Geberit AB
Folketshusgatan 1,
295 31 Bromölla
Sales.se@geberit.com
www.geberit.se

Geberit A/S
Lægårdsvej 26,
DK-8520 Lystrup
Sales.dk@geberit.com
www.geberit.dk

Geberit UAB Eesti filiaal
Kuma tee 2, EE-75312
Peetri Harjumaa
Sales.ee@geberit.com
www.geberit.ee

Geberit UAB Latvijas filiāle
Bieķensalas 21,
LT-1004 Rīga
Sales.lv@geberit.com
www.geberit.lv

Geberit UAB
Senasis Ukmerges kel.4,
Užubaliai, LT-14302 Vilniaus r.
sales.lt@geberit.com
www.geberit.lt